



CONFIGURATION AND KIT LIST

ARCS II CONSTANT CURVATURE WST® LINE SOURCE



ARCS II KIT LIST

CONFIGURATION

ARCS II/SUB SYSTEM	DESCRIPTION	6 ARCS II
LA8	Amplified controller 4 x 1800 W/4 Ω, ethernet network, AES/EBU	2
ARCS II	2-way active Constant Curvature WST® enclosure (with 2 coupling bars)	6
ARCPLA	Removable front dolly on wheels for ARCS enclosure	6
ARCS IICOV	Protective cover for ARCS enclosure	6
DO10	Speaker cable, 8 x 4 mm ² , CA-COM, 10 m length	2
DO3WFILL	Speaker cable breakout CA-COM > 2 NL-2 + 1 NL4, 3 m length	2
CC4FP	Speakon > Speakon adaptor	6
SP7	Speaker cable, 4 x 4 mm ² , NL4, 0.7 m length	4
SP25	Speaker cable, 4 x 4 mm ² , NL4, 25 m length	2
ARCBUMP	Rigging element to rig ARCS vertically	2
BUMP3	Rigging element for installing ARCS horizontally	4
LIFTBAR	Rigging bar for 2 x BUMP3 provided with 3 shackles	2

SB28 SYSTEM	DESCRIPTION	6 ARCS II
SB28	High power subwoofer, 2 x 18"	4
SB28PLA	Removable front dolly for SB28 enclosure	4
SB28COV	Protective cover for SB28 enclosure	4
SP25	Speaker cable, 4 x 4mm ² , NL4, 25 m length	4

SOFTWARE AND TOOLKIT	DESCRIPTION	6 ARCS II
SOUNDVISION	3D simulation software, available at www.l-acoustics.com	1

SERVICE STARTER KIT ARCS II	DESCRIPTION	6 ARCS II
KR HSBC34	Kit diaphragm for 3" driver - 8 ohms	1
KR HPBC34	Kit HP BC34 Driver 3" - 8 ohms	1
KR HPPH154	Kit HP PH154 Speaker 15" - 8 ohms	1
KR EL60	Kit 10 keeper rings 6mm with sling for dollies	1

SERVICE STARTER KIT SB28	DESCRIPTION	6 ARCS II
KR HPBM181	Kit HP BM181 Speaker 18"	1
KR CAPLATPIN	Kit 10 pins for dolly boards	1



6 ARCS II FOH SYSTEM



