



## K1-LA12X



# CONFIGURATION AND KIT LIST

## K1

### K1 KIT LIST - NOMINAL FULL PACKAGE

### KX STANDARD

K1 SYSTEM	DESCRIPTION	48 K1 - 24 K2
K1	3-way full-range active WST® enclosure	48
K1-PLA	Removable front dolly for K1 or K1-SB enclosure	0
K1-COV	Protective cover for K1 enclosure	0
K1-CHARIOT2	Chariot for 4 K1 or 4 K1-SB	12
K1-CHARIOTCOV	Protective cover for 4 K1/K1-SB on CHARIOT	12
DO.7	Speaker cable: 8 x 4mm <sup>2</sup> CA-COM 0.7m length	24
DO25	Speaker cable: 8 x 4mm <sup>2</sup> CA-COM 25m length	24
K1-BUMP	Structure for flying & stacking K1 and K1-SB arrays	4
K1-DELTA	Rigging accessory for rear attachment of 2 motors to K1-BUMP	4
K1-LASERMOUNT	K1 Laser mount	4
K-BUMPFLIGHT	Modular flight case for 2 K1-BUMP or 2 K2-BUMP	2
LA-RAK II	Touring Rack (complete with 3 x LA12X amplified controllers)	10
P1	Digital audio processor and measurement: 16 x 12 mic/line AES/EBU and AVB interfaces.	4
LA-RAK BUMP	Structure for flying 4 LA-RAK	3
DOM2	6 pair multiconductor cable AMP LINK 2m length	10
DOM45	6 pair multiconductor cable CROSS LINK 45m length	5
DOMF	Multipair cable adapter LINK-BREAKOUT 6 LR3 female	5
DOMM	Multipair cable adapter LINK-BREAKOUT 6 LR3 male	2
DOMP-2	Male/Male adapter LINK-EXTEND for AMP & CROSS LINK	2
KARA	2-way active WST® enclosure: 2 x 8" LF + 3" HF diaphragm	12
SP.7	Speaker cable: 4 x 4mm <sup>2</sup> NL4 0.7m length	8
DO25	Speaker cable: 8 x 4mm <sup>2</sup> CA-COM 25m length	4
DOFILL-LA8	Speaker cable extension for active 2 way enclosures CA-COM > 2 NL-4 length 3.5m	4
KARA-DOWNK1	Flying bumper for rigging KARA under K1 or K1-SB	4
<b>K1-SB SYSTEM</b>		
K1-SB	K1 System subwoofer 2 x 15"	24
K1-PLA	Removable front dolly for K1 or K1-SB enclosure	0
K1-SBCOV	Protective cover for K1-SB enclosure	0
K1-CHARIOT2	Chariot for 4 K1 or 4 K1-SB	6
K1-CHARIOTCOV	Protective cover for 4 K1/K1-SB on CHARIOT	6
DO25	Speaker cable: 8 x 4mm <sup>2</sup> CA-COM 25m length	8
DOSUB-LA8	Speaker cable breakout for passive enclosures CA-COM > 4 NL-2 length 5m	8
K1-BUMP	Structure for flying & stacking K1 and K1-SB arrays	4
K1-DELTA	Rigging accessory for rear attachment of 2 motors to K1-BUMP	4
K-BUMPFLIGHT	Modular flight case for 2 K1-BUMP or 2 K2-BUMP	2
LA-RAK II	Touring Rack (complete with 3 x LA12X amplified controllers)	2
LA-RAK BUMP	Structure for flying 4 LA-RAK	1
DOM2	6 pair multiconductor cable AMP LINK 2m length	2
DOM45	6 pair multiconductor cable CROSS LINK 45m length	1
DOMF	Multipair cable adapter LINK-BREAKOUT 6 LR3 female	1



# CONFIGURATION AND KIT LIST

## K1

### K2 SYSTEM

K2	3-way full-range active WST® enclosure	24
K2-CHARIOT	Chariot for 4 K2	6
K2-CHARIOTCOV	Protective cover for 4 K2 on CHARIOT	6
K2-JACK	4 tilt adjustment screw jacks + bar for K2-CHARIOT	6
DO.7	Speaker cable: 8 x 4mm <sup>2</sup> CA-COM 0.7m length	12
DO25	Speaker cable: 8 x 4mm <sup>2</sup> CA-COM 25m length	12
K2-BUMP	Structure for flying K2 arrays (incl. 1 extension sling + 1 laser adapter)	4
K2-BAR	Extension bar for K2-BUMP	4
K1-DELTA	Rigging accessory for rear attachment of 2 motors to K1-BUMP	4
K2-LASERMOUNT	K2 Lasermount (compatible TEQSAS-SSE Prosight-Align Array)	4
K2-RAKMOUNT	4 mounting cradle for LA-RAK (incl. rack stabilizer)	4
K-BUMPFLIGHT	Modular flight case for 2 K1-BUMP or 2 K2-BUMP	2
K2-LINK	Rigging accessory for rear attachment of K2 below K1	4
LA-RAK II	Touring Rack (complete with 3 x LA12X amplified controllers)	4
LA-RAK BUMP	Structure for flying 4 LA-RAK	4
DOM2	6 pair multiconductor cable AMP LINK 2m length	4
DOM45	6 pair multiconductor cable CROSS LINK 45m length	2
DOMF	Multipair cable adapter LINK-BREAKOUT 6 LR3 female	2
DOMM	Multipair cable adapter LINK-BREAKOUT 6 LR3 male	1
DOMP-2	Male/Male adapter LINK-EXTEND for AMP & CROSS LINK	1

### KS28 SYSTEM

KS28	Flyable subwoofer 2 x 18"	24
KS28-PLA	Removable front dolly on wheels for 1 x KS28	24
KS28-COV	Protective cover for 1 x KS28	24
KS28-CHARIOT	Chariot for up to 4 x KS28	0
KS28-CHARIOTCOV	Protective cover for 3 or 4 x KS28 on KS28-CHARIOT	0
DO25	Speaker cable: 8 x 4mm <sup>2</sup> CA-COM 25m length	6
DOSUB-LA8	Speaker cable breakout for passive enclosures CA-COM > 4 NL-2 length 5m	6
LA-RAK II	Touring Rack (complete with 3 x LA12X amplified controllers)	2
DOM2	6 pair multiconductor cable AMP LINK 2m length	2
DOM45	6 pair multiconductor cable CROSS LINK 45m length	1
DOMF	Multipair cable adapter LINK-BREAKOUT 6 LR3 female	1
DOMM	Multipair cable adapter LINK-BREAKOUT 6 LR3 male	1

### TECH TOOLCASE

TECH TOOL CASE	System technician tool case fully loaded	1
----------------	--	---

### TRAINING

TRA-DOM	On-site training 1 day (domestic)	0
TRA-REG	On-site training 1 day (regional)	0
TRA-INT	On-site training 2 days (international)	1
TRA-ADD	Additional on-site training day	1
TRA-VOU1	1 day training valid for one participant	0



# CONFIGURATION AND KIT LIST

## K1

### SERVICE STARTER KIT K1

---

KR HSBC33	Kit diaphragm for 3" driver	3
KR HPBC33	Kit HP BC33 Driver 3" - 20 ohms	3
KR HPPH62	Kit HP PH62 Speaker 6.5" - 8 ohms	4
KR HPPH154	Kit HP PH154 Speaker 15" - 8 ohms	2
KR PIN163	Kit K1 6 ball head pins	1
KR PIN183	Kit K1 bumper 2 pins	1

### SERVICE STARTER KIT K1-SB

---

KR HPPH154	Kit HP PH154 Speaker 15" - 8 ohms	2
KR PIN163	Kit K1 6 ball head pins	1

### SERVICE STARTER KIT K2

---

KR HSBC34	KitDiaphragm for HP BC34II (3" driver - 8 ohms)	2
KR HPBC34	Kit HP BC34 Driver 3" - 8 ohms	2
KR HPFA61	Kit HP FA61 Driver 6.5" - 8 ohms	2
KR HPBC125	Kit 12" speaker - 8 ohms	2
KR PIN163	Kit K1 6 ball head pins	2
KR PIN1394	Kit 2 x pin 1394	2
KR PIN1542	Kit 2 x pin 1542	1

### SERVICE STARTER KIT KARA

---

KR HSBC34	KitDiaphragm for HP BC34II (3" driver - 8 ohms)	1
KR HPBC34	Kit HP BC34 Driver 3" - 8 ohms	1
KR HPPH85	Kit HP PH85 Speaker 8" - 16 ohms	2
KR PIN621	Kit 10 pins short round head screws & rivets	1
KR PIN601	Kit 10 pins long T-shaped head screws & rivets	1

### SERVICE STARTER KIT KS28

---

G03229	KR speaker KS28	2
--------	-----------------	---

### NOMINAL PACKAGE SPLIT 1/2 1/2

